Datasheet WiFi-TC





The WiFi-TC in the FilesThruTheAir^m range of sensors measures the temperature of the environment in which the probe is situated. This sensor is typically accurate to $\pm 1.5^{\circ}$ C. Data is streamed wirelessly over any WiFi network and can be viewed on a PC using our free software package or on the FilesThruTheAir^m Cloud.

During configuration, the sensor will search for an existing wireless network whilst physically connected to the PC. It can then be placed anywhere within range of the network. If the sensor temporarily loses connectivity with the network, it will log readings until it is able to communicate again with the PC application or FilesThruTheAir™ Cloud (max 30 days at 10 second sample interval). Although the FilesThruTheAir™ WiFi sensors have an impressive range this can be increased by using WiFi extenders available from www.filesthrutheair. com.

The WiFi-TC is a battery powered device with an internal rechargeable lithium polymer battery.

The LCD display includes several features including Max and Min readings and indicators for low battery, alarms, WiFi connection and signal strength.

The sensor is IEEE 802.11b compliant, supports WEP, WPA/WPA2 encryption and enterprise networks *.

Setting up your WiFi-TC is easy, using our free PC software. Choose to store your data locally on the PC, or make it universally accessible on the FilesThruTheAir[™] Cloud. Whichever you choose, you'll be able to view historic data in graphs or tables, and export it in various formats. At any time, you can change the sensor settings, including Name, °C/°F, Sample Rate, and High/Low alarm levels. Our software and firmware updates are available for free from www.filesthrutheair. com/support.

WiFi-TC has a protection rating of IP44. The unit is freestanding, but can be attached to a wall or surface using the bracket provided.

This sensor is supplied with a removable K type thermocouple probe but supports types J, K, N & T.

A range of recommended accessories, including ADSL routers, USB mains chargers and spare probes are available from www. filesthrutheair.com.

*MS-CHAPv2, PEAP, EAP-FAST, EAP-TTLS

www.filesthrutheair.com +44 (0)1425 651111 info@filesthrutheair.com

WiFi-TC Datasheet - TW

FilesThruTheAir[™] is a trademark of Corintech Ltd.

Issue 02 26/09/2014

Datasheet WiFi-TC



Specifications	Minimum	Typical	Maximum	Unit
Battery life		>6*		Months
USB supply voltage	4.5	5	5.5	Vdc
Operating temperature range	-20 (-4)		+60 (+140)	°C (°F)
Logging Period (user configurable)	10 sec	10 min	12 hrs	
Transmission Period (user configurable)	1 min	1 hr	24 hrs	
Temperature measurement range	-270 (-454)		+1300 (+2372)	°C (°F)
Temperature measurement resolution		0.1		°C
Temperature display resolution		0.1		°C
Temperature accuracy (probe dependent)		±1.5 °C		°C

Warning - do not exceed operating temperatures

Battery Life and Power Supply

The product will arrive partly charged but ideally you should charge it for 24 hours before use for optimum performance. The battery can be recharged (unit must be between 0 - 40 °C) via a PC, a USB +5V wall adapter, or a portable USB battery pack using the USB lead provided. It can also be permanently powered by a USB wall adapter or USB battery pack. Readings may be affected while the interanl battery is being charged. However, once charged, continued connection of the charger will have no effect.

*Battery life is dependent on: transmission period, WiFi encryption method, WiFi encryption key rotation frequency (determined by the router/access point), signal strength between router/access point and WiFi device, presence volume and type of WiFi traffic from other devices, sample rate and operating temperature.

Specifications liable to change without prior warning

www.filesthrutheair.com +44 (0)1425 651111 info@filesthrutheair.com

FilesThruTheAir[™] is a trademark of Corintech Ltd.

Issue 02 26/09/2014